



W celu podłączenia wiązki EmuTECH Injector 4L do wiązki Symbio 56 należy uciąć wiązkę zakończoną białym złączem Molex 10pin pozostawiając 10cm wychodzące z wiązki głównej. Następnie należy połączyć przewody wiązki 4L z 10-ciu przewodami pozostałymi pod odciecz wiązki ze złączem Molex. Należy łączyć ze sobą przewody o takich samych kolorach. W wiązce 4L pozostaną dwa wolne, dłuższe przewody, które należy podłączyć do wiązki głównej po usunięciu taśmy izolacyjnej przy złączu 56 pinów. Te przewody to: czerwono-biały - należy podłączyć do takiego samego koloru przewodu wychodzącego z pinu 24; niebiesko-biały - należy podłączyć do takiego samego koloru przewodu wychodzącego z pinu 27.

To connect the EmuTECH Injector 4L harness to the Symbio 56 harness, cut the harness with the white Molex 10-pin connector, leaving 10 cm coming out from the main harness. Then, connect the wires from the 4L harness to the ten remaining wires after cutting the harness with the Molex connector. Connect wires of the same colors together. In the 4L harness, there will be two remaining longer wires that need to be connected to the main harness after removing the insulation tape at the 56-pin connector. These wires are: red-white - connect to the same color wire coming from pin 24; blue-white - connect to the same color wire coming from pin 27.